

Graphical Navigation - Hierarchical Button Style

Graphical Navigation - Hierarchical Button Style

The following are example screen shots of the graphical navigation provided by DoveTrack WCS Dashboard.

In this version screens are screens with Windows buttons. While not a customizable as the HTML style screens, the navigation is more familiar to warehouse staff.

Figure	Purpose
Figure 1-Dashboard Splash Screen.	This is an example of the main splash screen. The purpose is to make access to most used programs from a single screen. Other programs are found on other screens. Navigation to these other screens is done by pressing bottom row of buttons. This may be customized.
Figure 2-Supervisor Splash Screen.	This is an example of a supervisory programs. Press Back to Main Menu returns to screen shown in Figure 1
Figure 3-Setup Splash Screen.	This is an example of a setup programs. Press Back to Main Menu returns to screen shown in Figure 1
Figure 4-Utilities Splash Screen.	Dove Track standard utility programs are found on this splash screen. Press Back to Main Menu returns to screen shown in Figure 1
Figure 5-Test Tools Splash Screen.	This is an example of test programs available to test mechanical equipment. Press Back to Main Menu returns to screen shown in Figure 1

Figure 1-Dashboard Splash Screen.



Figure 2-Supervisor Splash Screen



Figure 3-Setup Splash Screen



Figure 4-Utilities Splash Screen




Figure 5-Test Tools Splash Screen



Test Tools Menu

Carousel Movement

Light Tree

Sort Bar

Task Complete

Printing

Validation

